


SLINGBOW MODE


• Each time you shoot the Hammer Slingbow you must inspect the bands and frame for your own safety. If the bands show any signs of tearing or damage, DON'T SHOOT. Any tear no matter how minor may quickly rip and can lead to injury.

Prior to shooting and before each shot, make certain the lock mechanism is fully seated and in place. DO NOT shoot your slingbow without the lock fully engaged (see 'Assembly/Disassembly' for details.)

• Always use full length arrows in your slingbow and take special care to never draw the arrow beyond the circular brush arrow rest.



- Always inspect your arrows for damage prior to each shot.
- Discard and destroy any arrow that displays damage of any kind.
- The Hammer Slingbow may be used with synthetic vanes or natural fletching.
- Always insert the arrow into the circular arrow rest from the top/open slot. Do not attempt to insert the arrow from the shooter side of the slingshot, especially if shooting broadheads.



- If shooting fiberglass fishing arrows, make certain you position the nock to allow the slide stop be positioned at the 12 o'clock position and the slide is located on the point end of the arrow prior to shooting.
- Always use the wrist brace when shooting arrows.



- Always adjust wrist brace to ensure proper alignment of bands and arrow.
- DO NOT dry fire your slingbow.
- Install arrows and arrow bands as shown.



- The slingbow bands may be gripped by pinching the leather tab with thumb and forefinger or between first and second finger knuckles as shown. You may remove the leather finger tab to use a mechanical release.
- Always install the slingbow tubular bands using the



WHITE Ocularis plug as shown. DO NOT use the black Ocularis Plug with looped tubular bands for slingbow.

- Each time you shoot the Hammer Slingshot you must inspect the bands and frame for your own safety.



SLINGSHOT MODE

Prior to shooting and before each shot, make certain the lock mechanism is fully seated and in place. DO NOT shoot your slingbow without the lock fully engaged (see 'Assembly/Disassembly' for details.)

- Do not attempt to shoot arrows using the Slingshot head.
- The supplied head for shooting roundball projectiles is mounted lower to the handle in order to reduce wrist strain should the user choose not use the supplied wrist brace.
- Install bands as shown in the Ocularis™ Plug owner's manual supplied with your slingshot, or visit simple-shot.com/ocularis-plug-video-manual
- If you experience a fork strike, carefully inspect the slingshot head for damage. If you suspect damage, DO NOT continue to use the slingshot head. DO NOT dry fire your slingshot.

For more detailed information regarding the safe use of this product, please visit our website at: simple-shot.com and hammerslingshot.com and review the video owner's manual at simple-shot.com/the-hammer-video-manual



EVERYTHING SLINGSHOTS.®



THE HAMMER OWNERS MANUAL

The following is safety information from the Owner's Manual. This is not intended to replace the information included in the Owner's Manual, which should be read in it's entirety.

SLINGSHOTS / SLINGBOWS ARE DANGEROUS WEAPONS.

READ THE INSTRUCTIONS AND WARNINGS IN THE OWNER'S MANUAL THOROUGHLY AND CAREFULLY BEFORE USING.

THIS OWNER'S MANUAL SHOULD ALWAYS ACCOMPANY THIS SLINGSHOT AND BE TRANSFERRED WITH IT UPON CHANGE OF OWNERSHIP, OR WHEN THE SLINGSHOT IS LOANED OR PRESENTED TO ANOTHER PERSON.

⚠️ WARNING

SLINGSHOT SAFETY-YOUR RESPONSIBILITY

SAFETY MUST BE THE FIRST AND CONSTANT CONSIDERATION OF EVERY PERSON WHO HANDLES SLINGSHOTS OR SLINGBOWS.

This Instruction Manual is designed to assist you in learning how to use and care for your slingshot / slingbow properly.

Please contact us if you have any questions. Only after you are certain you fully understand the manual and can properly carry out the instructions should you practice loading, firing, or otherwise handling ammunition. If you have any doubts about your ability to handle or use a particular type of slingshot / slingbow safely, you should seek supervised instruction. If you are unable to locate supervised instruction you may write to:
SimpleShot, Inc. 1465 Sand Hill Rd., Suite 1014,
Candler, NC 28715 and they can help you.

The person possessing a slingshot has a full-time job. You cannot guess; you cannot forget. You must know how to use your slingshot safely!

Do not use any slingshot or ammo without first having a complete understanding of its particular characteristics and safe use.

- ⚠️ Slingshots / slingbows can cause severe personal injury or death.
- ⚠️ Treat each slingshot / slingbow as though it were a loaded firearm.
- ⚠️ ALWAYS WEAR EYE PROTECTION when you shoot or handle slingshots / slingbows. Eyewear should be compliant to the ANSI/ISEA Z87.1-2010 standard. Even if you are wearing correctional glasses already, it is necessary to wear such glasses in addition, as correctional glasses do not protect your eyes against a snapping band or other potential hazards.
- ⚠️ While slingshots / slingbows can be used recreationally, they are NOT toys. Those under the age of 18 should not use slingshots / slingbows.
- ⚠️ IT IS IRRESPONSIBLE AND UNWISE TO STORE OR LEAVE A SLINGSHOT / SLINGBOW THAT CAN BE DISCHARGED IN A MANNER THAT A REASONABLE PERSON SHOULD KNOW IS ACCESSIBLE TO A MINOR.
- ⚠️ Do NOT consume alcoholic beverages before or during shooting.
- ⚠️ KNOW your target and what's behind it- do not shoot at anything you don't intend to destroy.

- ⚠️ Make sure you have an adequate backstop for your target.
- ⚠️ Inspect the rubber band assemblies, slingshot / slingbow frame, AND attachment points before each shot for any signs of wear, breakage or cracks. DO NOT SHOOT IF BANDS, POUCH OR FRAME IS WORN OR DAMAGED IN ANY WAY. This includes nicks or small tears in the bands, damage to tubes, damage to pouch or frame!
- ⚠️ DO NOT dry fire your slingshot / slingbow.
- ⚠️ Replace damaged or worn bands immediately and retire a damaged frame. Do not attempt to repair.
- ⚠️ Do not shoot at hard surfaces or at the surface of water. Slingshot ammo may bounce off or ricochet and hit someone or something you did not intend to hit causing injury or death.
- ⚠️ DO NOT USE STONES OR ROCKS AS PROJECTILES- this can cause harm to the user, bystanders, your slingshot and bands.
- ⚠️ Bands contain LATEX. If you suffer from latex allergies or sensitivities, do not use.
- ⚠️ Always store bands in a cool, dark place when not in use. Do not expose bands to high temperatures (like your car on a summer day!)
- ⚠️ The bands are made from natural latex and WILL go bad at some point, whether you use them or not. Therefore they are excluded from any kind of warranty.
- ⚠️ NEVER FIRE A DAMAGED ARROW! - No matter what type, size, brand, or style of arrow you choose to shoot, you must always inspect each arrow for damage before each shot. Proper care of your new arrows can ensure years of quality performance. However, shafts can become damaged, and shooting a damaged arrow is extremely unsafe! Never assume ANY arrow is safe - not even a BRAND NEW arrow - until you have verified it yourself. It is your responsibility to check your equipment and be sure your arrows are always in good condition.
- ⚠️ Never draw the arrow beyond the brush arrow rest. Doing so may result in serious personal injury and damage to your slingshot / slingbow.

LIABILITY DISCLAIMER

Upon purchase and / or use, you (the user) agree to hold harmless SimpleShot, Inc. and its owners, heirs, employees, or assigns of any and all product liability. You agree that the above mentioned will not be held responsible or liable for any consequential, direct or indirect or special loss, injury, or accidents caused by the slingshots, bands, ammo or any other items that we produce, promote, and/or sell. In all cases, the user assumes full responsibility and all risk associated with the use of our products. It is your (the user's) responsibility to check with local laws in order to be compliant regarding slingshots and any other products that we produce, promote, and/or sell. Our products are not to be purchased or used by anyone under 18 years of age.

If you have any further questions regarding safe use or slingshot related inquiries, please contact us at <http://simple-shot.com/contact/>

ASSEMBLY/DISASSEMBLY

To install wrist brace:

Slide wrist brace into slot at base of handle. Install wrist brace retention plate with supplied screw to secure in place. To remove wrist brace, remove screw from retention plate and slide wrist brace out of slot at base of handle.

To install slingshot or slingbow head:


Insert the preferred head into the slot taking care that the SimpleShot logo is facing the shooter. Insert head until locking mechanism 'clicks' into place the head is inserted completely. DO NOT force the head into the slot backwards! Always visually inspect the locking mechanism to ensure it is in the fully seated position. While shooting, always double check to ensure the locking mechanism is fully engaged.

To remove slingshot or slingbow head:

Grasp handle as shown in your right hand and push locking mechanism outward with your forefinger while pulling parts away from one another. Please note, this will take some effort as the fit is exact. You may lubricate the mating surfaces with a silicone based lubricant to ease insertion and separation. We recommend dielectric grease found at any auto parts store. DO NOT use petroleum based lubricants.



NOTE: 'Shooter' side of slingshot = the side of the slingshot you see when holding the slingshot while shooting. 'Target' side of slingshot = the side of the slingshot facing the target when holding the slingshot while shooting



The Slingbow head may be used for roundball slingshot projectiles by removing the two 10-32 machine screws from the bracket which holds the circular brush arrow rest. To install bands, please refer to the Ocularis plug owner's manual included with your Hammer Slingshot / Slingbow.